

****DIY Spray Paint Letter Guide****

****Materials Needed:****

- Wooden or cardboard letters
- Spray paint (your desired color)
- Primer (optional)
- Sandpaper (optional)
- Paintbrush (for touch-ups)
- Protective gloves
- Masking tape
- Drop cloth or newspaper
- Clear sealant (optional)

****Instructions:****

1. **Prepare Your Workspace:**

- Lay down a drop cloth or newspaper in a well-ventilated area.
- Ensure you have proper lighting for visibility.

2. **Select and Prepare Letters:**

- Choose the letters you want to paint.
- If needed, sand the surface to create a smooth finish.

3. **Prime the Letters (Optional):**

- If the letters are dark or unevenly colored, apply a coat of primer and let it dry completely.

4. **Mask Off Areas (Optional):**

- Use masking tape to cover any areas you don't want to be painted.

5. **Spray Paint Application:**

- Shake the spray paint can well before use.
- Hold the can 6-12 inches away from the letters.
- Apply light, even coats, allowing each coat to dry before applying another.

6. **Check for Coverage:**

- Examine the letters for any missed spots or uneven areas. Use a paintbrush and touch up as needed.

7. **Seal the Paint (Optional):**

- Once the paint is fully dry, apply a clear sealant for added protection.

8. **Display Your Letters:**

- Allow the letters to cure fully before handling or displaying them.

****Tips:****

- Experiment with different colors and layering techniques.
- Make sure to work in a well-ventilated area to avoid inhaling fumes.
- Always follow the instructions on the spray paint can for best results.

****Safety Precautions:****

- Wear gloves and a mask to protect yourself from fumes.
- Keep the area clear of flammable materials while spray painting.