

### ### Letter Cutout Template Example

#### #### Template Name: Classic Serif A

##### \*\*Materials Needed:\*\*

- Plywood or MDF board
- Wood router
- Template material (plastic or cardboard)
- Clamps
- Safety goggles
- Dust mask

##### \*\*Template Dimensions:\*\*

- Height: 6 inches
- Width: 4 inches
- Cutout Depth: 0.5 inches

##### \*\*Instructions:\*\*

###### 1. \*\*Create Template:\*\*

- Draw the letter "A" in a serif font on your template material.
- Cut out the letter using a craft knife to create the template.

###### 2. \*\*Trace Template:\*\*

- Secure the template onto the plywood or MDF board with clamps.
- Use a pencil to trace around the template, marking the outline of the letter "A."

###### 3. \*\*Set Up Router:\*\*

- Attach the appropriate router bit for cutting out the letter.
- Adjust the depth of the router bit to 0.5 inches.

###### 4. \*\*Cut Out Letter:\*\*

- Carefully follow the traced outline with the router.
- Make sure to wear safety goggles and a dust mask during this process.

###### 5. \*\*Finish Edges:\*\*

- Use sandpaper to smooth out any rough edges after cutting.

###### 6. \*\*Final Touches:\*\*

- Paint or stain the letter "A" as desired for a finished look.

---

#### #### Template Name: Modern Sans-Serif B

##### \*\*Materials Needed:\*\*

- Plywood or MDF board
- Wood router
- Template material (plastic or cardboard)
- Clamps
- Safety goggles
- Dust mask

##### \*\*Template Dimensions:\*\*

- Height: 8 inches
- Width: 5 inches
- Cutout Depth: 0.75 inches

##### \*\*Instructions:\*\*

###### 1. Create a template of letter "B" in a modern sans-serif font.

###### 2. Trace the template onto your wood surface.

###### 3. Set up the router, adjusting for the depth of 0.75 inches.

###### 4. Cut out the letter "B," ensuring to maintain precision.

###### 5. Smooth out edges and finish as needed.

---

These examples illustrate how to create letter cutout templates for wood routing. Adjust sizes and fonts based on your project needs.